


Ground mode, speedometer set, KMH units




Ground mode with an offset set as landing zone at +250 m from take off place



Inflight mode




Altimeter view, between 1,000 feet and 10,000 feet



Altimeter view, below 1.000 meters




Altimeter view, above 10,000 feet



Altimeter view, above 1.000 meters

## DISPLAY CONFIGURATIONS





HOLD  UNTIL LOG SCREEN SHOWS

LOG


HOLD  UNTIL TOTALS SCREEN SHOWS

TOTALS



DOUBLE CLICK  TO SHOW UNIT INFORMATION

UNIT INFORMATION



**MANUAL GROUND RESET**  
**WARNING! USE ON THE GROUND ONLY!**  
 Read the user manual, page 18.